



LDB-01303/03
30916gs

CONTAINER LIFT-OFF HOIST AND SYSTEM

CROSS REFERENCE TO RELATED PATENTS

This invention is a continuation-in-part of my pending application allowed
to issue as Patent No. 6,619,904 on September 16, 2003. This relates to Figures
5 56-58 of that application.

An object is to use my swing arm's parallelogram hoist to transfer a
container from a truck or semi trailer backed up to swing the arms up to engage
hooks and lift the container off from the truck bed and to latch it up with a winch
so the truck can be driven out from under the container and to load the container
10 onto the truck by backing the truck under the hoist to align and engage the
container to lift the hoist to relieve the load from the winch to release it to the
truck when driven out from under the hoist, the hooks being controlled to
cooperate.

This is an overpass transfer device and system for transferring such things
15 as passengers, cargo, and bulk dump containers, racks or parts boxes between
trains and stations, conveyors or other vehicles or storage spots. This invention
includes the transfer cranes, containers, cars and stations that make this system.
The containers for passenger trains are of car width and made as a removable
section of the car body to be replaced by an equivalent section put in its berth on
20 the car with one pass of the loader. The passenger containers are preferably
keystone shaped as viewed from the side, so when lifted up from their berth in the

car they open up clearance at each end from the car body which fits against the container when set down thereon. The container is lifted by a parallelogram linkage frame suspended from a jib crane or overhead diagonal across-the-track traveling crane, or cranes depending from an overhead wheel or track.

5 It is an object to provide a loader for transfer of a container to and another from a spot on a train or vehicle simultaneously in either direction. It is a further object to transfer in a substantially horizontal plane.

 It is an object to provide a convenient container transfer station crane with self-engaging loadspreader for transfer of one or more containers from and/or to a
10 car in a moving train with one transfer crossover and further to do this using only the train's movement to power the loader during transfer and further to do this with minimum lifting of the containers.

 It is an object for the loader to transfer during its crossover of a train in an arc or diagonal in the direction of the train's movement and clear the train after the
15 crossover. It is a further object to then empty or unload the container and move the loader to re-engage the train to recross over the train and a further object to set the container on the same car and berth from which it was removed.

 It is an object to provide a safe, simple, dependable, automatic, and low cost overhead loader operated by the train's movement.

20 It is an object to have successive loaders on the same support transfer successive and selected containers either from or to the train or both.

 It is an object to keep the loadspreader parallel to the train car while crossing the train and to turn it end for end if needed for the next transfer.

It is an object to lift the loadspreader with or without a container and pass back above the train if desired.

It is an object to remove and deposit containers on a vehicle in one transfer pass over the vehicle.

5 It is an object to use a parallelogram swinging linkage as the container transfer hoist, which will lift automatically as needed for clearance.

It is an object to provide one hoist for both the outgoing and incoming containers.

10 It is an object to remove a container and insert another in the same spot on a railway car or other vehicle moved to swing the loadspreader on links to lift, shift sideways, and lower by gravity while aligned for transfer.

It is an object to provide straight across the car coupling between the car and the loadspreader with close alignment from either side of the car depending on direction of movement.

15 It is an object to provide a keystone shaped container in side view and further to provide cars with one or more berths each extending across the car with ends of the berth sloped to fit, hold, and seal the container as desired.

It is desired to provide a tapered hood for enclosing each end of a container to seal to the car ends and open end clearance when the hoods are lifted.

20 It is an object to accurately position and pin the container on the car and to release the pins when the container is engaged by the loadspreader and either lifted or supported to roll out of the car while held by the loadspreader.

It is an object to provide container transfer with this system between truck and rail vehicles or vehicles of different width.

It is an object to provide lift hooks on the container which lift to unlock the container from the transport vehicle before being lifted farther to keep the hook engaged if not lifting the container during transfer.

It is a further object to preaccelerate the container to coupling speed before coupling a vehicle above coupling speed.

It is an object to provide these features also for material handling, amusement rides, and as a toy as well as full size.

These other and further objects and features should become evident to those skilled in the art by study of this specification with reference to the drawings wherein:

Figure 1 is a plan view of a railway passenger, express, or mail station with a jib crane positioned to be engaged and turned by the train to take one container out and put another in its place on the train.

Figure 2 is a side elevation of Figure 1 with near container removed.

Figure 3 is a side elevation aligned with Figure 2 showing the train passing at a time during which both containers are lifted in the train.

Figure 4 is a perspective view of the loader.

Figure 5 is an end elevation of the loader's hoist and loadspreader for side coupling and lifting the containers.

Figure 6 is a perspective view looking up at the loadspreader.

Figure 7 is a perspective view of the container.

Figure 8 is a side view of a container lift hook and rod.

Figure 9 is a perspective view of a portion of the car showing an empty berth for the container.

Figure 10 is a side view of a container hook latch.

5 Figure 11 is a partial cross sectional view inside the car looking toward the container berth to show a side coupling plate.

Figures 12 and 13 are cross sectional elevations of the car passing the loader taken respectively when the side hooks are engaged and when in the center of transfer.

10 Figure 14 is a side elevation taken on line 14-14 of Figure 12.

Figure 15 is a plan section taken on line 15-15 of Figure 14.

Figures 16 and 17 are respectively side and end sectional elevations of a container being lifted from the car by a top lifting loadspreader on the loader.

15 Figures 18 and 19 are respectively plan and side views of the lift for the container of Figures 16 and 17 aligned for transfer with car from the right.

Figure 20 is an end elevation of Figure 19 but with a single container lift loadspreader.

20 Figures 21 and 22 are successive plan views of a double pivot bottom lift loader engaging a train respectively when side coupling and when extended under a container for transfer from the train.

Figure 23 is an end elevation of the loadspreader with containers in position of Figure 22.

Figure 24 is a side elevation of the car of Figure 22 with a container on the loader's lift arms in its berth.

Figures 25, 26 and 27 are respectively end sectional, side, and plan views of an end lift loadspreader engaging a container with a car in the train.

5 Figure 28 is a perspective view of a variation of the loadspreader of Figures 25-27.

Figures 29 and 30 are plan and side elevations of a station having a double arm jib crane top lift loader engaging a container and car in a train moving right to left passing the station.

10 Figure 31 is an end sectional elevation of Figure 30 showing a gantry with jib crane for full circle operation over trains on two tracks.

Figures 32 and 33 are side and end elevations of a loadspreader for the loader of Figures 29-31 having a catapult mounted for accelerating a container to near train speed before coupling.

15 Figure 34 is a schematic station and track plan for two directional operation.

Figure 35 is a schematic station and track plan for a loader to serve three intersecting rail lines and for transfer therebetween.

20 Figure 36 is a schematic station plan of successive loaders setting off and picking up containers from conveyors indexing between unloading and reloading the car after moving three car lengths.

Figures 37 and 38 are side elevations of a dump loadspreader respectively engaging and dumping a dump container.

Figure 39 is a plan view of a dump station for receiving, dumping, and returning the dump containers to the same cars.

Figures 40 and 41 are respectively side and end elevations of a variation of the hoist and loadspreader on the jib crane engaging an end dump container on a car and shown dumping in phantom.

Figures 42 and 43 are respectively sectional plan and side views of a hoist with loadspreader engaging cargo containers on a well car, Figure 42 being taken on line 42-42 of Figure 43.

Figures 44 and 45 are respectively plan and side elevation views of a crossover station with a skewed gantry crane replacing the jib crane of Figure 1 to provide a constant angle of traverse.

Figure 46 is a partial section on line 46-46 of Figure 44 to larger scale.

Figures 47, 48, and 49 are respectively plan, side, and end views of a skewed crane crossover station with loader handling a cargo container for highway-rail transfer, Figure 48 being minus the near container and Figure 49 being taken in the direction of arrows 49 in Figure 47.

Figures 50 and 51 are respectively plan and side elevations of a variation of the loader with crane supported on roller topped columns to roll at a diagonal across the track.

Figure 52 is a broken oblique side and top projection of this loadspreader linked to the supporting frame shown with one of the supporting columns.

Figure 53 is an end view of this loadspreader linked to a traveling crane rail.

Figure 54 is a plan view of a larger station similar to Figure 47 to smaller scale.

Figure 55 is an end elevation taken in the direction of the arrow 55 in Figure 54.

5 Figures 56, 57, and 58 are respectively plan, side and end views of a truck to loader transfer.

Figure 59 is a perspective view of a lift truck for the side hook container.

Figures 60 and 61 are respectively side and end elevations of a lift table for the station of Figure 54 engaging a container on a loadspreader.

10 Figure 62 is a plan view of station roller bed platforms at the same level as car bed for roll-on roll-off transfer, so the hooks need not lift the containers for transfer.

Figures 63 and 64 are aligned side elevations on lines 63-63 and 64-64 of Figure 62, the containers in Figure 64 being positioned on the roller bed for
15 engagement when the loadspreader is swung up.

Figure 65 is an isometric view of alignment and positioning devices for the roller platform positioning a container for engagement by the loadspreader to be coupled and lifted by the train.

Figures 66 and 67 are aligned end elevations of respectively the positioning
20 and roller beds holding a container in phantom in position before engaging the loadspreader with the car in direction of arrows 66 in Figure 65.

Figure 68 is a plan view of a variation of the car and loadspreader side coupling.

Figure 69 is a side elevation of the loadspreader and car of Figure 63 with hoist for clearing over a train.

Figures 70 and 71 are respectively left and right partial end views of the loadspreader aligned to engage the car of Figure 68.

5 Figure 72 is a side elevation of the loadspreader of Figure 69 lifted to clear over the train.

Figure 73 is a side elevation of a bilevel passenger car with loadspreader positioned to lift off a container section of the car.

10 Figures 74 and 75 are aligned plan and side elevations of a cargo container on a car engaging a loadspreader respectively before and after lifting, showing the movement of the car for this and showing the release of end latches of the container.

15 Figures 76 and 77 are side elevations of the side coupling latch and release on the car of Figures 74 and 75 to larger scale in respectively pinned and open positions as controlled by the loadspreader.

Figure 78 is an end elevation of Figure 77.

Figure 79 is a partial end sectional elevation of the loadspreader engaging a container on the left before lifting to engage the one on the right.

20 Figure 80 and 81 are respectively partial plan and side elevation of a container of Figure 79 showing a hook support-drop bar for dropping the hooks on the side of the container for pre-coupling the container before the loadspreader is lifted.

Figures 82, 83, and 84 are respectively plan and side elevations of a passenger car having a container (removable section) with end hoods for end clearance during level transfer.

Figure 85 is a plan view of the end of this container.

5 Figure 86 is a perspective view of this container with near hood removed.

Figure 87 is a perspective view of the hood.

Figure 88 is a perspective view of an end of this car without the container in its berth.

10 Figure 89 and 90 are respectively plan and side elevation of a crane run along the track and a skewed traveling crane thereon having a crossover carriage accelerating to couple a car for transfer of containers.

Figure 91 is a schematic plan of the crane run at a smaller scale extended to show cranes running for successive transfers with cars in the train.

Figure 92 is a schematic of a successive starter for the cranes of Figure 91.

15 Figure 93 is a schematic side elevation of a pendulum starter set to push a container on a roller bed soon before being coupled by a loadspreader.

Figures 94, 95, and 96 are respectively plan, partial end, and side views of a crossover crane for automatic transfer of parts boxes to and from a tow truck being pulled by an under floor tow conveyor.

20 Figures 97 and 98 are perspective and end views of a variation of the hooks for the container to loader coupling.

Figures 99-100 are respectively partial side and end views of a variation of these hooks.

Figures 101 and 102 are respectively partial side and end views of another variation of these hooks.

Figure 103 is an end elevation of a swing out lift hook extended from a side at top of a container and shown as closed flush in phantom.

5 Figures 104 and 105 are respective side and end views of a swing lift hoist transferring a container to and from a truck.

Figures 106 and 108 are plan, end, and side views of the support for a corner of the hoist.

10 Figures 109 and 110 are side and end elevations of a swing lift hoist transferring a cargo container to and from a trailer.

Referring to the drawings and in particular to Figures 1-15, where crossover loader 18 is positioned to transfer a passenger container 20 from railway passenger car 22 (including a baggage, express or mail car) in a train moving from right to left on track 24 and insert a second container 20 in place of the one removed. Station platforms 26 are positioned where convenient for loading and
15 unloading the containers on the loader.

The loader has one or more jib cranes, arm 28, mounted with an offset bracket 29 on pivot post 30 on top of a vertical column 32 to rotate horizontally in one or more arcs for transfer over track 24 or other vehicle way. The jib crane 28
20 carries a loadspreader 34 on parallel linkage frame 36 in an arc crossing the track centerline at an angle of about 35-45° to the track.

The jib crane 28 has a load shaft 38 secured depending vertically from its outer end. A sleeve 39 is supported to turn on shaft 38 and is secured central

through the top frame 40 of parallelogram linkage 36 having its parallel links 44 supporting a bottom frame, loadspreader 34, to swing vertically parallel to track 24 to lift and lower to engage, release, and move or lift containers 20. Linkage 36 is a swing lift hoist. Links 44 at each end are preferably connected by cross braces 45, 5
Figures 4 and 5. This parallelogram hoist 36 is held parallel to track 24 by means such as roller chain 46 connecting a sprocket 47 fixed on sleeve 39 and frame 40 to an equal sprocket 47' concentric on pivot post 30. Sprocket 47' is held in fixed position during transfer but turned to turn the loadspreader end for end if needed by means as an integral ring gear 48 secured depending fixed on sprocket 47' and 10 driven by spur gear 49 on a worm gear motor 50 or could be fixed to the pivot post. The jib crane has an internal ring gear 51 secured depending from the bottom of the offset bracket 29 concentric with the pivot post. It is driven by spur gear 52 driven through an electric clutch 53 by reversible gearmotor 54 to rotate the jib arm 28. The clutch disconnects motor 54 to free the loader to be turned by 15 the movement of the car.

The loadspreader has two vertical columns 55 depending central one at each end to support a container on each side. Each column 55 has an alignment bracket, block 56, secured at right angles to the length of the loadspreader. A lift plate 58 is secured to and extends above each block 56 on each side to face a 20 vehicle 22 for engaging a hook plate 60 extended from a side near each end at the top of container 20 to engage, support, lift, and release the container. Blocks 56 have wheels 61 to hold the container out at the bottom level when supported on the two plates 58 on either side of the loadspreader. Blocks 56 extend down below

container 20 when hooked on plates 58, Figures 12 and 13, and have rollers or wheels 62 to travel across the floor or guide track 64 in berth B while supporting the containers and guided on the end walls of the berth. Lift plates 58 have a shallow “V” notch spanning the top length at about 120° included angle to cradle
5 hooks 60 on the container. The angle of the “V” notch is less than the angle of tangency to the swing position of links 44 where the coupling block leaves the berth so hook plates 58 can release from hooks 60 and let the loadspreader drop. The shorter that links 44 are the greater the angle of tangency for a given lift, but the greater the force needed to lift it to that height. Hooks 60 have a keyway or
10 pocket 67 for plates 58 to engage in to secure the container on the loadspreader. Plates 58 can have side deflecting wings 68 to prevent catching on the side of the vehicle.

The container 20 has a bottom and sides securely connected and ends tapering outward from the bottom to form a keystone shaped container, Figure 7,
15 which fits into an upward lengthening opening, berth B, Figure 9, which fits the container and can seal the ends of the container to the car body yet provides clearance when the container is lifted. The container has recessed end doors 70 and the car recessed doors 71 aligning to open the car to the container.

The loadspreader has a bracket 72 extending endward from each block 54
20 supporting a wheel 74 one on each side at a height of the hook plates 58 to rotate parallel the loadspreader and recessed in from the face of hook plates 58 so as not to engage the side of the container or car but engage a coupling plate 76 extended straight from the side of the approaching car 22 at the rear end of its berth to swing

the loadspreader up on links 44 to engage hooks 60 on the car's container for transfer, lift the loadspreader to roll across the berth with its containers hooked on, and clear rollers 74 to cross the berth. Each plate is slanted parallel to its end of the berth, which helps the lift. Plate 76 can be overshot if the jib crane is not
5 turned by the torque before roller wheel 74 reaches the top of the plate.

Referring to Figures 7-9, the container's hook plates 60 are each secured on top of a shaft or rod 78, Figure 8, extending down inside the sides of the container and optionally through the floor. Rods 78 are mounted in sleeves to slide up and down and turn 90° out from the side of the container for engagement
10 for transfer. These hooks can be interlocked with door locks or pins so plates 60 can only be turned out when the container is ready for transfer. The rods 78 on each side have linkage and levers 79 between them to be manually or otherwise turned to extend or retract the hooks. Rods 78 can extend down into pockets 80 open out to the sides of the car to hold the container from rolling or sliding off
15 before hooks 60 are engaged and lifted and after disengagement by plates 58 dropping rods 78 into pockets 80 on the exiting side of the car. Hooks 60 have a shallow slope down to the end to slide a plate 58 up into pocket 67, Figure 8, for plate 58 to key in to secure the container hooked, and release when blocks 56 swing down from a container left on the car. Hooks 60 when fully lifted support
20 the container on brackets 81 on rods 78.

A slide coupling plate 76 is at each end of berth B parallel to the end of the berth mounted to shift transversely to be extended on the rear entry side of the berth. It is extended out to engage the coupling roller 74 on the rear block 56, i.e.

the one facing the approaching car, to swing linkage 36 up into vertical alignment for hooking the container to the loadspreader on the entry side of the car. Only rods 78 on the lifted hooks are lifted. Rods 78 on the entering container are lifted only on the entering side while those on the far side remain down and engage in
5 pockets 80 to hold the container from overshooting the berth and also stop the transverse movement of the loadspreader relative to the car momentarily until the linkage swings down, dropping plates 58 from hooks 60.

Rollers 62 hold the loadspreader at a height across the car to keep hooks 60 engaged and their rods 78 lifted above the floor and support but preferably only lift
10 the containers on the car if there is interference and hold them and the loadspreader in alignment during transfer. Stops 82 on the hoist engage links 44 to limit the lift. A retarding cylinder 83 is connected between top frame 40 and one or more links 44 to limit the swing and descending speed. Longitudinal rollers 84 recessed across the floor of the berth can support the containers to roll
15 out or in the berth during transfer. Rollers 84' in the ends of the berth also can guide the containers out and in.

Preferably the berth and container are extended endward in a step 85 at each end at the roof line. These endward extensions of the roof of the container better cover passageways between the container and car and open more room for
20 rollers 74 to cross over the car between the outgoing and incoming containers, and cover a shelf at each end of the berth with latches or catches 88 for securing the container on the car. A catch tab 88 extends down from each corner of the container's roof to straddle the sides of the car recessed therefore at the

passageways 85. This can be a fixed tab if the container is lifted or preferably a latch bar, Figure 10, pivoted at 89 to the side of the container and extending endward over bracket 81 on hook rod 78 to be lifted by hook 60 to clear over the car through this passage. This can be in addition to or replace rods 78 in pockets

5 80.

Referring to Figures 9 and 10, coupling plates 76 are mounted to slide across the car to extend from either side for transfer or be recessed in from the sides. A gear 96 engaging gear rack 97 along the side of each plate 76 is driven by motor 98 controlled to extend the coupling when right for transfer and retract it

10 after transfer.

A laser light 100 along side of track 24 directs a beam up to reflector 102 on the bottom of blocks 56 and back to receiver 104 to position the loader precisely by control of gearmotor 54, Figures 2 and 12.

OPERATION

15 Referring to Figures 1-3 and 12-15, coupler 76 extended on the near side of car 22 approaching the loader from the right engages the right far side roller 74 on the loadspreader, Figure 14. The coupling 76 moves the loadspreader forward and up on links 44, lifting the side plates 58 into aligned container lift hooks 60 to lift their rods 78 out of pockets 80 and lifts coupling blocks 56 to a height to enter

20 wheels 62 into berth B to guide in end corners of the berth across the car. The force pulling linkage 36 provides a torque that will turn jib arm 28 counter-clockwise carrying the loadspreader across the car supported on wheels 62 at a height sufficient to keep plates 58 engaged with hooks 60 until coupling blocks 56

run off the far side of the car letting the loadspreader swing down setting the incoming container in its place. Links 44 lift the containers higher with increasing force if needed for clearance as in Figure 3 because of the keystone design. Stop 82 limits the upward swing of the loadspreader as the train turns the jib arm to move one container out and one into the car. It works in reverse with the opposite coupling plate extended from the far side of the car to engage the vacant side of the loadspreader with the train moving left to right and sets the removed container back in as it removes a container from that car. It will similarly transfer a single container either to or from the car with the same movements.

10

VARIATIONS

Referring to Figures 16-19, where the loadspreader 34T has a wide frame supporting hooks 58T thereunder to engage in hook bails 60T to lift container 20T from the top. The same car 22 and berth B takes container 20T, and the loader is the same as 18 except for the loadspreader. Hooks 58T face oppositely on each side of the loadspreader 34T to hook container 20T coming from the direction to hook's face and release a container 20T on the opposite side of the loadspreader to that train.

Container 20T has two connected bails or hooking loops 60T at each end each in a different line of travel to engage on hooks 58T arranged to engage them in either direction the car is facing. Bails 60T are lifted by the lifting of the loadspreader on links 44, releasing the container for transfer. The bails at each end of the container are connected to a lift arch rod 78T extending across under the top of the container and down in each side into key pockets 80 on the car and

20

engage the container to lift it after rods 78T are lifted by hooks 58T to a height to travel across the car.

5 Loadspreader 34T has two posts 55 depending from its frame with wheels 61 for engaging the side of each container to help steady it when needed. Posts 55 support blocks 56 and the same configuration of rollers 61, 62 and 74 to be engaged by car 22 similarly as described. The posts at each end are connected by crossbracing 125. Rollers 62 support the loadspreader to roll across floor 64 at a height to keep hooks 58T engaged in bails 60T.

10 Referring to Figures 19 and 20 where the loadspreader 34T' for handling one container at a time is missing the left side and is supported on links 44 centered over the right side. The loader would remove the container, Figure 19, moving to the left and would load it on a train moving in the opposite direction.

15 Referring to Figures 21-24, the jib arm 28 can support a bottom lift loadspreader 34B on a loader otherwise as described herein afore. The loadspreader 34B has a lift column 55B depending from each end of its frame on its centerline. Columns 55B are connected by a beam 138 between them at the bottom. At the bottom of each column and under beam 138 are pivotally supported two transfer arms 140 each pivotally supporting a platform 142 connecting the arms on one side of the loadspreader to swing as a parallelogram under container 20B and the same along the opposite side. A roller wheel 144 under each outer corner of each platform 142 rolls on the side of the car until it enters a berth opening 146 under the container with torque from motor 54. The sides of opening 146 are vertical and straight across car 22B to guide rollers 144 to

20

guide the platform 142 under the container as arms 140 are rotated by movement of the train in passing from right to left moving the engaged platform from the position shown in Figure 21 to that in 22 and 23 where stops 158 on beam 138 limit the rotation of arms 140 to stop when fully extended as shown in Figure 22
5 and when retracted endward as in Figure 21. Beam 138 extends endward beyond columns 55B and down below arms 140 to support wheel 62 on each side to roll in line with rollers 144. Wheels 144 and 62 guide the loadspreader through the car, and wheels 62 support the loadspreader to travel across the car.

The arms 140 on the opposite side of the loadspreader turn oppositely from
10 retracted position to extend to pick up a container and retract to leave a container on trains in opposite directions from opposite sides of the track.

Locating pins 170 on platforms 142 and on container supporting ledges in the berth engage in holes in the bottom of container 20 to locate and hold it on car 22B and loadspreader 34B. Additional pinning of the containers is recommended
15 on the car after transfer thereto.

Referring to Figures 25-27, end lift loadspreader 34E for loader 18, otherwise as described, engages end trunions 60E at the top central on each end of container 20E for lifting. The loadspreader is a frame supported on links 44 and has a transverse hook plate arm 58E depending from each end and extending out
20 from each side to extend under and engage a trunion 60E. Plates 58E straddle the ends of the container and engage hook pockets under the trunions to lift the container. Each plate arm 58E has an up tapered end with horizontal wheel 74 to roll across an open passage 85 in the ends of berth B. The hook pockets have a

high back wall to stop travel of the plate arm when aligned to lift the trunions. Wheels 61 and 62 are on a common central axis mounted on the bottom of the loadspreader to engage the side of respectively the container and car to roll up thereon and into passage over the car with wheels 62 supporting the loadspreader
5 guided on ends of the berth across the car.

The approaching car engages its extended trailing side coupling plate 76 with the rear facing roller 74 on the loadspreader. This moves the crane to cross over the car to where rollers 74 run under the trunions and end tapers on arms 58E press them down against the trunions until seated in pockets when wheels 62
10 engage the car to stop the crane. Continuing motion of the train lifts links 44, lifting the loadspreader and container until wheels 62 are lifted to clear through the coupling passages 85 in the roof of the car, starting the crane to continue across the car, lifting out a container if in the berth and inserting one it carried on by the loadspreader. Transverse flanges 172 on the faces of plates 76 facing the berth
15 extend in aways from the sides of the car to hold the loadspreader from lifting until the trunions are engaged.

The outer ends of the trunions 58E can recess into recesses ER in the car roof to locate and secure the container in place when set down until otherwise secured as by longitudinal pinning from the ends of the berth.

20 Referring to Figure 28, the loadspreader of Figure 25-27 can be modified to more easily enter the coupling passage with less lateral movement by mounting the latch hooks 58E on the outer end of a horizontal parallelogram linkage 174 having parallel rotating arms 175 supporting a link connecting hooks 58E into a

lift fork to swing out to carry plates 58E parallel under the trunions when the trailing roller 74 is engaged by a side coupling plate 76. Blocks 56E support parallelogram linkage arms 175 on a pivot column 176 on one or both sides of the loadspreader for one or two containers respectively. Arms 175 are each a truss
5 mounted to swing horizontally between a top and bottom extension of connected blocks 56E on links 44. Linkages 174 rotate easily to couple the trunions before appreciable lifting. Stops 158 hold the linkage from turning out beyond 90°. Wheels 62 mounted on the bottom of block 56E support the loadspreader to roll through the coupling passages. When hooks 58E are extended under the trunions,
10 stops 158 hold the arms extended while the loadspreader is swung up on links 44 to lift the container that is on the car until wheels 62 roll up into the coupling passages 85 to hold the container lifted and the jib is turned by the car's movement to swing the container out the far side of the car. Linkages 174 turn out oppositely on opposite sides of the loadspreader to be pushed out from the car after a
15 container is set down on the car. The arms 175 on an empty side of the loadspreader are extended before transfer and held extended by a dent on the supporting arms and are retracted after transfer by the train pushing them to turn parallel to the side of the loadspreader.

Referring to Figures 29-31, loader 18L has two or more parallel rotating jib
20 arms 28 of equal pivot length each supported on a pivot post 30. Each pivot post can be supported on a column 32 or suspended by other support such as gantry frame 180, Figure 31, shown spanning two tracks 24 for full circle operation. A

separate gantry 180 can support each pivot post 30, or the gantries can be connected and made a traveling gantry.

Two or more arms 28 are recommended for long containers up to car length. Each arm 28 has a depending pin 38 pivotally supporting a top frame or
5 horizontal link 40L pivotally connected under them forming therewith a horizontal parallelogram linkage frame. Links 44 are suspended from horizontal link frame 40L to swing parallel thereto and to tracks 24, and support the loadspreader 34L for side by side transfer of containers 20LT. Chain 46 is run around sprockets 47 secured each to an arm 28 on pivot 38 to turn the arms together parallel through
10 dead centers, not shown.

Loadspreader 34L selected for disclosure has top lift hooks 58T and includes additional features over the top lift loadspreader 34T which features are equally applicable to that loadspreader of Figures 16-19. Loadspreader 34L extends beyond the ends of the containers to hold a depending block 56T at each
15 end to travel across car 22L in passage 85 through the roof of the car at each end of the berth for container 20LT. End roof extensions on the container cover the passage. Side couplers 76, which can be extended from opposite ends of the berth BL to either side have the trailing one set out to engage the trailing roller wheel 62 on the side of the loadspreader facing the car for transfer as described.

20 Referring to Figures 32 and 33, the long top frame 40L that connects arms 28 into a horizontal parallelogram in Figures 29-31 can support a catapult 190 with track 192 and short parallelogram lift car 194 to run on its track and be moved to approach a little higher train speed before coupling to the car for

transfer. Car 194 has links 44 supported on wheels 195 on beams 192 forming the top frame 40L. Links 44 are connected by a horizontal link 196 near the top and by the loadspreader 34C on the bottom. The loadspreader 34C is shown fitted for top lifting similar as in Figures 29-34 but shorter to accelerate a container like 20L
5 (except short) along track 190 before being met by a car like 22LT except with a berth to fit the container.

The catapult could be and operate similarly as those shown in my U.S. Patent No. 4,082,042, issued April 4, 1978, Figures 1, 8-14, and 17-20, and be a traveling loadspreader 34C for holding the container to accelerate to car speed
10 before transfer. Optionally the berth on a car could be near car length with a catapult in reverse to catch loadspreader 34C with container along side of and at the front of the car and decelerate them relative to the car as they reach the speed of the car at the rear.

STATION OPERATION

15 Referring to Figure 34, loader 18 having a loadspreader 34 which is rotated 180° or more by motor 50 can turn the empty side to align for transfer at a position A for a train from the left or position B for a train from the right to serve trains from either direction in any order.

20 If the loadspreader is not reversible, as with multiple jib arms, or if preferred to simplify the loader, Figure 34 provides a station plan to serve trains in either direction in any order. It has a loader 18 mounted on pivot post 30 to rotate over track 24 in the first and second quadrants of the circle and retractable couplers 76 at ends of the car's berth.

Starting with the loader at A as in Figure 1, a first train from the right moves the loader from A to B and the next train if from the left moves it back to A. When successive trains are coming from the right, every other one after the first has coupler 76 extended to the opposite side for use between C and D, and the loader is positioned at C to align for that train and is moved to D by the transfer. It waits at D for a train from the left or is moved to A for a train from the right. Likewise, a second loader 18 can be added to work the second track 24T especially if all traffic is in one direction and opposite on each track. Positions E, F, G, and H for track 24S correspond to positions A, B, C and D for track 24 in the direction of the arrows.

Referring to Figure 35, one or more loaders 18 are on a single pivot post 30 equally spaced from three crossing tracks T1, T2, and T3 to exchange containers with trains thereon. Three loaders 18 are shown but can represent three positions of the same loader. Each transfer is less than a 90° rotation across the track at a slope of about 45° at the crossing of track center by the load shaft 38 and in the direction of the train's travel. After each transfer the container removed from the train is moved to a station platform 26 to wait for the next train on any of the tracks from any direction and is moved into position for transfer. The parallelogram linkage is turned by motor 50, Figure 1, to align the loadspreader parallel to the track and the jib arm positioned by motor 54, Figure 1, for the transfer.

Station plan, Figure 36 has a loader 18 positioned relative to track 24 to cross trains twice to transfer containers 20 from railway cars to a conveyor 200

and containers 20 from a conveyor 200 to reload cars as they are moved in the direction of the loaders' rotation.

Referring to Figures 37-41 for a bulk unloading hoist and station, where in Figure 39 rotary loaders 18 are shown mounted on pivot post 30 to rotate
5 thereabout in a circle crossing track 24 twice in transfer runs two car lengths apart. The containers are dump containers 20D as in my U.S. Patent No. 6,354,782 B1, filed June 4, 1998, except their loadspreader has double ended hooks 58D and the container rods 60D are on and parallel over end doors 204 to lift the container and open the lower door when dumped while on the far side of the track from pivot
10 post 30. Thus with trains traveling left to right the containers are removed from cars 1, 2 and 3, dumped and returned to the same car as the train is moved or indexed moving the loaders. The loaders are otherwise moved by motor 54 between transfers with the train where the motor's clutch is disconnected for movement by the train.

15 The loadspreader for bulk dump container 20D has an upper frame 40H which in plan is an "H" frame supporting a lower "H" frame loadspreader 34H on parallel links 44 near each end and one on each side at the middle of the "H" frames to swing parallel to the car. A riser 206 across the center of frame 34H extends up to pivotally support an end of lift arms 208 to swing parallel between
20 the sides of frame 34H and links 44. Two lift arms 208 are pivotally mounted on each side of riser 206 to swing up and down together to support a hook bail 209 to swing up and down between their outer ends parallel to the car to engage and disengage hooks 210 on the container. A cable or cylinder 212 is used to swing

the bails to hook and unhook as in my mentioned U.S. patent. Arms 208 are lifted by cables 214 connected near their outer ends and each run up to a cable drum and hoist on the outer end of frame 40H to lift or lower, tilt and dump the container with one arm raised and the other lowered as shown in Figure 38 or in phantom in
5 Figure 40, where hooks 210 are on top of end doors to swing open to dump.

Frame 34H has depending end coupling guides 54 which travel on rollers 62 across the car in end passages 85. A roller 216 on each guide 54 is rubber covered to engage the ends of the container to align it for transfer onto the car. The container is set between end and side locating horns or sides and needs no
10 pinning. This loader can remove, dump from either end and return the container 20D to the same car 22 while moving as described with Figure 39.

Referring to Figures 42 and 43, the loader of Figures 40-41 is adapted for lifting standard ISO boxes using a typical loadspreader lift frame 220 mounted to swing on ends of links 222 in place of bails 209 and is otherwise as described with
15 Figures 40-41. It can lift out or insert one or two stacked containers at a time on well car 22W while the car is moving.

Referring to Figures 44-46, the jib crane is replaced by a skewed bridge crane crossing over track 24 at an angle of about 30-60° to provide a constant force angle for moving the crane's carriage with the train to cross over parallel to
20 the train at this constant angle of travel instead of in an arc as the jib crane provides.

Skewed crane ways 240 are supported on columns 242 to span across the transfer area over track 24 at a diagonal of 33-55° skew angle. The car 22,

containers 20, loadspreader 34 and hoist are as in Figures 1-15. The hoist linkage arms 44 are pivotally suspended from upper frame 40 having a central pivot 38C suspending it from a skewed crane carriage 246 spanning ways 240 parallel to track 24, so when the loadspreader is coupled to the car as described and lifted on
5 links 44 to height to clear into berth B the force on the crane carriage 246 moves it across over car 22 to transfer one container 20 out and put one in its place on the car. The hooks 60 or container engagement can be of any type described.

The crane 246 is supported on wheels 248 which run on crane rails 240. Horizontal guide wheels 250 at each end of each side roll against the insides of the
10 crane runs to take turning forces. The hoist is rotated to turn the loadspreader and its load around end-for-end and hold it parallel track 24 with a solenoid release pin 252 connecting frame 40 to the crane carriage 246. Frame 40 can be turned by gearmotor 50 driving gear 48C with spur gear 49 when the pin is lifted. The crane is driven by reversible gearmotor 54 connected through electric clutch 63 to drive
15 wheels 248 to move on its bridge rails 240 in either direction. Clutch 53 disconnects the drive to free the crane to roll to cross over the train when engaged therewith.

SOME WAYS TO TRANSFER CONTAINERS AT STATIONS

Container Lift Transfers (Lift On and Lift Off):

- 20 1. Lower a lift platform to set container on the loadspreader and raise the platform to lift the container off, Figures 60-64.
2. Lift the loadspreader by cable winch or hydraulic cylinder on the hoist to lift off or set down container on a truck and drive out from under, Figures

56-58, or lift and lower using the truck and a latch to latch up the hoist when lifted by the truck.

3. Use a lift truck to set container on or lift from side of loadspreader, Figure 59.

5 Container Transfer Substantially Level (Pull On and Push Off):

1. Place container on platform at same elevation as car bed and in position to be engaged by the loadspreader to lift only the container's hooks when the loadspreader is engaged by the train and lifted, Figures 62-67, or deepen key slots 67 in hooks 60 to engage without lifting.

10 2. Release latched up hooks 60 to drop enough extra to engage the loadspreader while the container is supported on a roller bed to move for level transfer with only the hooks lifted, Figures 79-81.

STATION ADJUNCTS, DETAILS, AND VARIATIONS

Referring to Figures 47-49 for a cargo container transfer station that lifts
15 containers 20F on and off the train in either direction, craneway 240 crosses over track 24 at 35° approximate minimum from straight across with a skewed carriage 246 thereon parallel to track 24 supporting a long hoist 36 on center pivot pinned or fixed. Hoist links 44 support a loadspreader 34F for containers 20F for truck to rail transfer.

20 The car 22F has a low elevated ledge bulkhead coupling way 85 transverse across each end of the berth as long as the container is wide and fixed open coupling plate 76 along the endward side of each ledge and extended to the car side on the right near side and on the left far side on top of the car's bed. The

ledge is 6-12 inches high – enough for wheels 62 on blocks 56 to lift the loadspreader to engage and lift hooks 60 on the coupled side of the container and lift the container possibly two inches or minimum clearance across their berth before dropping the loadspreader to swing back down to lower the incoming
5 container into its berth. Car 22F has a berth for holding a cargo container 20F of width for highway trucks – narrower than car 22F. Therefore, wheels 62 clear over the car bed to be engaged and lifted by the right coupling plate 76. A roller 262 on the bottom of each end of the loadspreader 34F engages the side of the car to align parallel before side coupling and guides longitudinally between bulkheads
10 85 during transfer.

This freight station has a platform 26F along each side of track 24 under the runway of crane 18F. Each platform 26F has rollers 272 on axes transverse to track 24 to support flat bottomed container 20F so it can be rolled along the dock and onto a truck that has a similar roller bed. A container can be rolled from the
15 truck onto a platform 26F to a position where the loadspreader can be moved against it from track side and later when the loadspreader is engaged by coupling 76 to swing up aligned to engage hooks 60 and lift wheels 62 to ways 85 which supports the loadspreader to keep hooks 60 lifted across the car while transferring containers laterally on the car. When the loadspreader swings down from ways 85
20 with the removed container, the incoming container is set down aligned in the berth. The removed container clears over the platform on the far side of the track until the loadspreader swings down unhooking the container to move along the conveyor. A push rail 276 of rollers is supported along the outer side on top of

each platform and connected and moved by cylinders 278 to push the container and/or loadspreader against the train when ready to engage the car as will be described more fully with Figures 65-67.

Figures 50-53 show a simplified variation of the crane to support the
5 loadspreader to run diagonally across while parallel to track 24. This crane has rails 240 supported on rollers 280 spring mounted on top of columns 242. Rails 240 have bottom channels 282 turned legs down to guide on wheels 280. Rails 240 are connected by cross-members 284 and diagonal stiffening cables 286. The loadspreader is supported on links 44 parallel to track 24 and pivotally connected
10 to brackets 288 secured to the bottom of rails 240. Wheels 280 are driven by gearmotor 54 through electric clutch 53 which disengages for the train to move the crane when the motor is not energized to position the crane.

Referring to Figures 54-61 for features of a more extensive station, where the craneways 240 are extended at each end beyond a single platform for various
15 loading arrangements and can have a number of carriers on the craneway to enable successive transfers with the same train in passing in either direction. This station has craneways 240 supported on cross spans 296 on columns 242 spaced for the container to clear between so the crane runs can be extended.

Added features include direct loadspreader to truck transfer, Figures 56-58,
20 where a truck trailer TT is driven on driveway D under the craneway and a crane carrier aligned against the side of the trailer has a loadspreader 34 supported on links 44 to be lifted by the truck backing up. A cable secured to winch 298 is hooked to the loadspreader to hold it up to support a container 20F above the

trailer, which can then be driven away. The trailer can be loaded by driving under a lifted container to support it lifted and releasing the dog of the winch to lower the container on the truck when driven forward. Loadspreaders so lifted are lowered and disconnected from the winch before transfer with the train.

5 The container can be transferred to and from the loadspreader with lift truck LT, Figure 59. Truck LT has lift plates 58 replacing the usual forks. Plates 58 are adjustable to spacing of hooks 60 on the containers. This requires a wide driveway and turn area under the crane or at the end of its runway for turning containers 20F.

10 Referring to Figures 60-61 where a typical roller bed lift platform 26L is raised to lift the container off the loadspreader and be moved lengthwise on the conveyor. To load, the container is aligned lengthwise on the platform, lifted, the loadspreader moved against it, and the platform lowered aligned to engage hooks 60 onto plates 56 of the loadspreader.

15 Referring to Figures 62-67, it is preferred to provide same level, plane, or roll-on roll-off transfer, since the hooks 60 will then not need to support the load but only take push and pull forces. Accordingly, the platforms 26F along track 24 under the crane are normally at car bed level and have rollers 306 turned at the angle of the crane-way in frames 307 held at that level and alternate with rollers
20 308 transverse to track 24 in lift frames panels 310 which are recessed below but lift above rollers 306 to move containers parallel to track 24 to roll endward onto truck beds or conveyors, and to position for engagement with a loadspreader.

The preferred engagement between the loadspreader and containers on the dock is shown in Figures 62-64 where the loadspreader when engaged by the train is swung up where its lift plates 58 engage under hooks 60. These figures also show two half length containers 20H in place of one full length container by
5 additional lift plates 58 so there are at least two for each container on each side of the loadspreader and interbox connectors 312.

Referring to Figures 65-67 for further details of container positioning means on the platforms, the container in phantom is resting on rollers in waiting position for approximate alignment of the car for transfer in a train from the right
10 represented by its side coupling 76. The container was positioned lengthwise the platform by live rollers 308 when lifted and more accurately by cylinders 314. A side pusher angle bar 316 is supported above rollers 308 and moved sideways by toggle links 318 guided in tracks 319 and actuated by cylinder 320 to push the container sideways against the loadspreader. An extension arm 322 from bar 316
15 has an upstanding pusher plate 324 for moving the loadspreader sideways to engage the side coupling on the car. Pusher 324 is pivoted at 326 and forced upright by spring cylinder 328 pushing against stop bracket 336 on the end of arm 322 which also has a wheel 338 on vertical axle to roll against the side of the car when the loadspreader is pushed far enough to align for side coupling over the bed
20 of the car. Arm 322 is supported on rollers 340 to move transversely to track 24 below the top of rollers 308 on the platform.

Since pusher plate 324 extends above the roller platforms to engage the loadspreader's coupling block 56 which is above the platforms, plate 324 is hinged

at 326 to swing away from track 24 to let a container move onto the roller beds during transfer from a train. The pusher plate 324 is returned upright by spring cylinder 328 when the container is moved from over it.

5 The lift platform, Figure 67, has a channel frame 348 supporting rows of rollers 308 on shafts at right angles to track 24. Frame 348 is supported on links 350 pivotally connected between it and a bottom support secured on the ground. Roller frame is lifted by one or more cylinders 352 connected between the support and a lever link 350'.

10 Referring to Figures 65 and 67, curb angle 354 is mounted along the track side edge of the lift platform one leg up and one in on end pivots 356 to swing in and let the container move onto the platform and then lift back up to stop the container from rolling off the side of the platform. It is supported on springs 358 to recess only counterclockwise in these figures.

15 Platform 26F is lowered when the loadspreader is engaged by the train by exhausting cylinder 352 so the container rests on rollers 306 to roll at the transfer angle and curb 354 is below the top of rollers 306 so when hooks 60 are lifted and pulled by the loadspreader after being lifted by the train the container is pulled by its hooks to roll onto the car having bed of lengthwise rollers 84 for ease of transfer.

20 Referring to Figures 68-72 for a simplified variation of the car and loadspreader coupling which is generally applicable, car 22F has end bulkheads 358 establishing ends of the berth for container 20F. The container slips between tapered ends of the bulkheads from either side. The car has coupling keyways 85

across from side to side on the bulkheads at a height for wheels 62 on guard rails 358 to lift to support the loadspreader on its pass through the car. The bulkheads are as wide as the container and centered transversely on the car leaving space for a wheel 62 to engage a protruding coupler plate 76 on the rear end of the car.

5 Latches 88F connected by tubing 360 at each end of the berth are mounted to be opened by wheels 62 lifting and holding them open while passing through these coupling keyways.

As a separate variation, the hoist of Figures 68-72 has long links 44 and lift cable 366 connecting each end of the loadspreader with one or more turns around

10 drum 368 connected by electric clutch 370 to gearmotor 372 to lift the loadspreader and preferably a container thereon to a height to cross above the train, so the crane can make more than one pass per train.

Referring to Figure 73 where a bi-level passenger car 22BP has a container section 20BP with keystone tapered ends engaged for transfer by a loadspreader

15 34P, stairs 376 to each end of the lower level enable passage when the container berth is closed off for transfer.

Referring to Figures 74-78 for details of the securement of container 20F to car 22F and release when engaged by the loadspreader, car 22F has a latch arm assembly 88F at each end which straddles the end of the container to hold it and

20 swings up to free it and open passage for the loadspreader and container when the latches at both ends are lifted by rollers 62 on the loadspreader. Each latch assembly has two parallel arms 382 spaced apart on a lift bar or pipe 360 and pivotally mounted on hinge pins 89 on each bulkhead to swing up and away from

the container. Pipe 360 extends out to the limit of car width on the bottom of arms 382 and over coupling channel 85 on both sides of the berth and rests in channel 85 at a height for wheels 62 to go under for coupling and lift and roll thereon lifted across the car. Wheels 62 lifted at both ends of the car lift latches 88F at both
5 ends to free the container as hooks 60 are engaged with plates 58. Wheels 62 have a ball caster 385 central in their hub extending out to help it roll in any direction.

Referring to Figures 79-81 for an arrangement to lower hooks 60 to engage a loadspreader before it is lifted, hooks 60 drop to the position shown at the right in Figure 79 normally, which will be engaging when the loadspreader is lifted by
10 the train. Rather than wait for the loadspreader to lift, hooks 60 can be dropped further, as at the left in Figure 79, to hook with the loadspreader by sliding a support bar 410 in either direction to let the coupling shafts 78 drop through slots in bar 410. Bar 410 is a channel run legs down along the inward side of the container with a shaft welded in line to each end extending into a tube 418 and
15 hole through each end of the container. Springs 422 center bar 410. Roller 424 supports the channel on which hooks 60 rest. A bar is inserted in the hole from either end of the container to push bar 410 so shafts drop through slots 412 on each side of where shafts 78 rest, so the shafts drop through the slots when the loadspreader is aligned to hook. This is optional to swinging the loadspreader up
20 into the hooks. The container should be on rollers to move freely.

Referring to Figures 82-88, the passenger car 22PL has a near full length container 20PL with tapered end hoods 430 to lift separate from the container to open clearance gaps between the container and car during transfer. As seen in

Figures 85 and 86, each end of the container has box channel track 432 secured vertically up each corner slightly recessed from the side on the container into which conveyor rollers 434 on the shield 430 roll up and down on the container. Hood 430 has only a roof and two tapered sides 436 at full car width and height to seal against tapered ends of the car's berth, Figure 88. The hood has hooks 60 on each side fixed to a short rod 78 and mounted to swing into a roof pocket 72 and be turned out for transfer. Rollers 434 are secured on axles through a "T" member 438 turned inward to roll up and down interlocked on tracks 432. The sides of the hood extend down to tapered insets below the floor of the car to help secure and seal to the car. The hoods provide clear passage between end doors in the container and end doors to the berth.

The loadspreader, Figure 84, has side coupling columns 55 that pass over the tapered ends of the berth. Wheels 62 guide the containers across. Hook plates 58R and 58L have two nests for hooks 60, an upper one to engage to lift the hood and a lower one to engage the container after the hood is lifted to clear the car. Hooks 60 on the container are as in Figure 8 and hook the container on the car pockets 80.

PREACCELERATION BEFORE COUPLING

Referring to Figures 89-92, one or more traveling cranes 444 run on a craneway track 240R supported on columns 242R along each side of track 24 for a transfer runway. The traveling bridge cranes 444 are skewed at about 30-50° and each has a carriage 246 that supports the hoist 36 and loadspreader 34F parallel to track 24 to cross over track 24 when coupled for transfer and powered by motor 54

to return. Carriage 246 is driven by engagement of its loadspreader with a car in the train to cross over track 24 on its bridge crane. Traveling bridge cranes 444 are each driven by a motor 448 to be preaccelerated to couple with a particular car in the train. Successive bridge cranes 444 transfer with successive selected cars
5 22F in the train. An electrical contact running rail 450 is run along the craneway and segmented in carrier lengths 452 at each end. A similar rail 454 is run along track 24 and segmented correspondingly at each end in equal lengths 456.

Referring to Figure 92, cranes 444 ready for transfer are lined up at the right end of craneway 240R for the next train. Each crane has its motor 448
10 connected between a contact shoe 458 and ground. The shoe 458 of the first crane contacts the running rail 450 and the rest contact their segments 452. Each car 22F has a series DC generator 460 (same as motor 448) connected across a contact shoe 462 in series with switch 463 to ground. The long contact rail 454 is connected to close a circuit when the first car from the right with switch 463
15 closed entered its shoe 462 on this rail through generator 460, contact rail 454 (about half the crane run), coil of relay 464A to ground, lifting relay 464A closing a circuit from rail 454 through its front contacts to craneway contact rail 450, shoe 458 to motor 448 to ground to start the first crane to accelerate to coupling speed before side coupling with that car. When the second car with a closed switch 463
20 connects the first segment rail 456 at the left in a circuit closed from its generator 460, shoe 462, that rail segment 456, front contacts of relay 464A to coil of relay 464B, it closes a circuit from the first contact rail 456 through front contacts of relays 464A and 464B to line 466, coil of relay 464B to ground and from line 466

through front contacts of relay 464B to first segment 452 from the left, shoe 458 and motor 448 of the second crane to accelerate it to couple the second car for transfer. Likewise the second segments 452 and 456 are connected when the next car with switch 463 closed enters the second segment 456.

5 Referring to Figure 93 for an alternative way to preaccelerate a container before engagement with a loadspreader, a raised weighty parallelogram pendulum 470 is supported by lifting and latching up against the back of container 20 on a roller conveyor 26R is released to swing down to accelerate the container when the train reaches a point at a particular speed at which the container will be engaged by
10 the loadspreader.

APPLICATION IN MATERIAL HANDLING

Referring to Figures 94-96 for an application of the crossover transfer crane to material handling, a tow chain conveyor 480 is run under the floor F to pull truck 22M with parts box 20M past crane carriage 246M which runs on three
15 parallel box rails 240M diagonally across over conveyor 480 at about 45°. Angle rails 24M guide the truck through the transfer. Crane carriage 246M has a top frame 40M supported by trolleys 248M to run on the rails 240M supported from the ceiling. A parallelogram linkage hoist 36 depends from the carrier frame 40M supporting a loadspreader 34M having side plates 58 for engaging under hooks 60
20 on a side of parts box 20M. The loadspreader has a bump rail 488 extending along each side the length of the parts box at the bottom and a vertical roller 76M beyond each corner. One roller 76M at opposite corners is bracketed out to engage a roller 74M across each end of truck 22M. Those on the near right and far left are

spaced sideways out to engage the forward roller 74M of truck 22M. Those on the near left and far right are in line with the sides 488 but also extend endward equally for rollers 74M to key between. Wheels 62 support the loadspreader to run across the truck 22M on its rollers 74M to hold plates 58 up in hooks 60 for
5 transfer.

With truck 22M being pulled to the left, its front roller 74M engages the far left front roller 76M on the loadspreader when aligned for lifting. Continued movement of the truck lifts the loadspreader on links 44 engaging plates 58 into hooks 60, lifting the parts box, and applies force to move the crane at the transfer
10 angle about 45° with conveyor 480 when at a height to clear the bed of the truck, crossing over the truck to remove its container and replace it with another if one is engaged on the near side of the loadspreader. The loadspreader drops when the near roller 76M leaves roller 74M at the front of the truck, setting the leaving parts box down in place on the truck at a rate determined by the setting of the retarding
15 cylinder 82. The loader will transfer in either direction of movement of the truck with the loadspreader positioned with an empty side facing the truck.

Returning to Figure 86, stop pins 496 on the ends of the container through the top of tracks 432 limit the lift of the hoods so the container can be lifted by hooks 60 on the hoods or the container rolled on or off the car without lifting the
20 container - only the hoods which latch the container to the car.

Referring to Figures 97-102, the side hooks 60 can be a continuous bar 60B for mounting along the top of the sides of the containers to be hooked onto bar 58B mounted along the side of the loadspreader to better distribute the load

and secure hooking. The rolled section 60B has the key slot 67 and hook lip as does plate hook 60 but has ribs or pins 500, shallow “V” gussets 502, or rollers 504 spaced to correspond with the shallow “V” notches on plates 58B to hook thereon with lateral alignment. Bar plates 58B engage the top of slots 67 to
5 support the container so rollers 504 are free of load. Gussets 506 can be added for strength along the top of bar hooks 60B.

Referring to Figure 103 for another variation of the hooks 60, lift hooks 60S are secured on a pivot shaft 510 to swing out from flush with the side of a container 20 to be engaged by plates 58 or 58B as a type of hook suited for toys
10 and models of this invention.

Referring to Figures 104-108, truck T is shown backed under a lift frame 40 for lifting off and holding cargo container 20. Frame 40 has four columns 242 each pivotally supporting a depending pivoted link 44. A loadspreader 34 has a frame supporting the usual twist locks 56T spaced to engage in standard corner
15 castings 60T at the four top corners of the container. The loadspreader has four depending legs 600, one at or near each corner, pivotally connected at the bottom to the links to swing the loadspreader in a parallelogram linkage lengthwise the truck. A weight W extended from one or more links 44 biases the links to swing out toward the front of the truck. A cable 604 with weight W is attached to the
20 rear of the loadspreader to a winch 298 to hold the loadspreader up when pushed up backward. The truck has a bed for the container with a front tab 606 extending up to engage the front end of the container. The loadspreader has a rear tab 608 extending down to engage the rear end of the container.

The weight W on links 44 or other biasing means extends the loadspreader out from the dock so corner twist locks clear the top of the container on the truck. Tab 608 at the end of the loadspreader nearest the dock extends down to be engaged by the container when the truck backs the container against it. This pulls
5 the loadspreader to swing back and down to engage the twist locks on the corner castings of the container. Continuing backing the truck swings the links up counterclockwise lifting the loadspreader with container straight up off of the truck bed enough to clear the supporting pedestal supports on the truck bed. Winch 298 winds up its rope 604 with weight W or other biasing means.

10 When the truck is backed against the dock, the container is lifted off the truck and is held by the winch so the truck can be driven away forward.

To pick up the container supported on the hoist at the dock, the empty truck is backed up under the container on the hoist. Tab 606 on the front of the truck bed engages the forward end of the container as the truck nears the dock.
15 This lifts the container and loadspreader by swinging the links 44 up and relieves the winch of the load so its dog can be disengaged and the truck moved forward lowering the container onto the truck. The twist locks are then released by existing control air. Then the truck is driven forward to swing the loadspreader up lifting the twist locks out of the top corner castings.

20 Referring to Figures 109 and 110, this hoist is applied to lifting a container off a semi trailer and shifting it on trolleys 612 to reload on an adjacent vehicle.

Having thus described some embodiments and applications of my invention I do not wish to be limited to those disclosed but intend to cover this

LDB-01303/03
30916gs

invention by claims to be submitted to cover all variations, applications, and parts
which are within the spirit and scope of this invention.